

Barista Coffee Scoop Kit Instructions

You will need:

Drill bits: 3/8"

Knurl Bushing

Drill, Tube & Square your blanks & mount on your mandrel



Turn your blank down to the bushings. Polish & finish blank

Lay out your parts based on the diagram below

Assembling the pen

1. Press one coupler into one end of the tube.
2. Press the other coupler into the other end of the tube. We recommend using care to prevent breaking of key ring attachment
3. Thread scoop into coupler. O ring optional – goes on shaft that you thread in.
4. Thread key ring onto key ring end.