

Bead Kit Instructions

You will need:

Drill bits: 8mm or 5/16"

Bead Bushing

Drill, Tube & Square your blanks & mount on your mandrel



Turn your blank down to the bushings. Polish & finish blank

Lay out your parts based on the diagram below

Assembling the pen

1. Press one coupler into one end of the tube.
2. Press the other coupler into the other end of the tube.