

Swift Click Pen Kit Instructions

You will need:

Drill bits: 3/8"

Strider/Swift Click Bushing

Drill, Tube & Square your blanks & mount on your mandrel



Turn your blank down to the bushings. Polish & finish blank

Lay out your parts based on the diagram below



Assembling the pen

1. Press the front coupler to one end of the tube
2. Press the rear click section to the opposite end
3. Insert the ink refill and screw.
4. Thread the tip end onto the nib assembly